



Labino® Torch Light ^{UVG2}



MAKES IT BRIGHT

365 nm | >12 000 µW/cm² | 211 gram

- The Labino® Torch Light^{UVG2} is a small-sized, lightweight, UV-A LED flashlight designed for quick inspections and “hard-to-reach” spots.
- The lamp measures 15.9 cm long (6.3 inches) and weighs 211 gram (7.4 oz), battery included.
- The Labino® Torch Light – UVG2 produces a narrow intense ultraviolet beam measuring over 12 000 µw/cm² at a distance of 38 cm (15 inches). The centre of the light beam is 30 mm (1.2 inches) Ø and the whole light beam is 70 mm (2.8 inches) Ø, at a distance of 38 cm.
- The Labino® Torch Light^{UVG2} contains one (1) ultraviolet light emitting diode (LED). The LED creates UV light that peaks at 365 nm making it suitable for industrial, leakage and security applications.
- Full power is reached instantly. The on/off button is positioned in the back of the lamp to prevent accidental activation.
- At full charge the battery provides up to 3 hours of use. Recharge from a normal outlet or vehicle with included chargers. The kit also includes an extra battery.



TECHNICAL SPECIFICATION

UV LED

- UV source: UV A LED (1)
- Intensity: >12 000 µw/cm² at 38 cm (15 inches)
- Visible light: < 20 Lux
<1.86 Foot candle
- Wave length: 365 nm
- Distribution angle (beam): spotlight

DISTRIBUTOR:

TemaFlux srl

Via N. Tartaglia 11, Gussago (BS), Italy
Tel +39 030 322079 – Fax +39 030 311872
temaflux@temaflux.com – www.temaflux.com

Battery

- 2200 mAh Lithium-Ion, 3.7 volts
- Running time: approx. 3 hrs
- Charging time: approx. 8 hrs
- Requires one (1) battery to operate

Charger

- One (1) 100-240 VAC charger for use from electrical outlet
- One (1) 12 V charger for use in vehicle via cigarette lighter connection
- Capacity: two batteries can be charged simultaneously

Dimensions

- Length: 15.9 cm (6.3 inches)
- Weight exc. battery: 166 gr (5.8 oz)
- Weight inc. battery: 211 gr (7.4 oz)

The Labino® Torch Light Kit

- UV LED flashlight
- Charger for use from electrical outlet
- Charger for use in vehicle via cigarette lighter connection
- Two (2) batteries (1+1 extra)
- Belt holster
- UV Block glasses
- Carrying case (optional)

Certificate

- All components included in the Labino Torch Light lamp are RoHS certified according to 2002/95/EG

Labino AB shall not be held liable for any errors or omissions resulting from the test procedures that were used in validating performance of any Labino AB product nor for unforeseen errors or omissions in digital or printed material.